

Glue Instructions.Important!!

1. To Be used only at Room Temperature (at least 18° C)

Stir glue until it has a consistent colour. Spread glue on the clean wood

and rear foil side with a small(1mm) toothed spatula. Let glue air dry about 10 min.(should be “touch-dry”).

Apply foil to drum using pressure.

The finished drum can only be drilled after 24 hours. Mounting hardware should be done after 48 hours.

See Videos and Tips and Tricks Page

1.Verarbeitung bei Raumtemperatur (mindestens 18 Grad Celsius)

Umrühren bis der Kleber eine einheitliche Farbe hat.

Auftragen des Klebers auf Kesselaußenseite und Folieninnenseite
Mit einer 1 mm feinen Zahnpachtel.

Trockenzeit ca. 10 Minuten .

Folie dann mit Druck anpressen (von außen mit einem zusammen-gerollten Tuch oder ähnl.)Von innen im Kessel mit der Hand dagegendrücken.

Bohren nach 24 Stunden und Montage der Hardware nach 48 Stunden.

Siehe www.stdrums.de Videos und Tips page

Gerd Stegner